

Q	SMITH® JAY R. SMITH MFG. CO.® MEMBER OF MORRIS GROUP INTERNATIONAL POST OFFICE BOX 3237 MONTGOMERY, ALABAMA 36109-0237 (USA) TEL: 334-277-8520 FAX: 888-377-7818 www.jrsmith.com MEMBER OF: MEMBER OF: MEMBER OF:				LOCATION 	
	NON-FREEZE GROUND HYDRANT					
	1 1/4 (32), 1 1/2 (38) or 2" (51) CONNECTIONS					
	NOTES: 1. Recommended Box-out 9 1/2(240) x 9 1/2(240). 2. All Jay R. Smith hydrants are manufactured with "NO-LEAD" brazing rings and USDA approved lubricants. 3. The AB100, AB1953, California Lead Law, and NSF/ANSI Standard 61 - Drinking Water System Components are not applicable to Jay R. Smith hydrants as they do not convey/dispense water for human consumption through drinking or cooking. 4. Dimensions shown in parentheses are in millimeters. 5. FOR IRRIGATION PURPOSES ONLY. 6. Temperature Range: 33.0°F to 140.0°F (0.6°C to 60.0°C). B(Depth of Bury) = 02(610), 03(915), 04(1220), 05(1525), 06(1830), 07(2135) or 08(2438) Feet REGULARLY FURNISHED: Bronze Non-Freeze Ground Hydrant with "T" Handle Key and Cast Iron Hydrant Box Inlet and Hose Connection. Size Furnished as Indicated by Figure Number Selected. VARIATIONS: ☐ 1/8" (3) NPT Drain Hole in Box -N ☐ 1/8" (3) NPT Drain Hole in Valve Housing -NV ☐ "Water" Cast on Cover -W OPTIONAL MATERIALS: ☐ Nickel Bronze Box -NB ☐ Polished Bronze Box -PB ☐ Rough Bronze Box -RB					
TECHNICAL DATA						
Non-Freeze Ground Hydrants are supplied with a special valve housing which prevents freezing of hydrant during non-use periods. The valve housing must be installed below the frost line which prevails for the area of installation. The valve housing has a drain hole which drains the casing when the hydrant is shut off. In effect, there is no water in the casing during non-use periods. Since water from the drain hole is normally allowed to drain into the ground, the valve housing should be set in a bed of gravel. Water drained from the casing can then seep into the ground. Some locations which require Non-Freeze Ground Hydrants cannot tolerate water draining from the drain hole. Examples are parking garages, plazas and roof decks used for recreational purposes. Often in these types of applications the valve housing will protrude into a finished area which is not subject to freezing temperatures. To eliminate the problem of water drainage in this type of installation, Smith can supply a tapped drain hole in the hydrant box and a tapped drain hole in the valve housing. Through these tapped drain holes, water accumulation in the box and the water from the valve housing drain hole can be piped to a suitable drain.						
FIGURE NUMBER	5812, 5813, 5814					
	Q	P	N	M	REV.	
2-4-25		Revised Notes		HS	BW	
8-4-23		Removed Function		HS	CL	
3-22-23		Revised Note 3		KK	JT	
2-5-13		Revised Notes		KBW	CL	
				BY	CKD. BY	
				WEIGHT POUNDS	VOLUME CUBIC FEET	
				FIGURE NUMBER		
				5812, 5813, 5814		



WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

FIGURE NUMBER	5812,5813,5814-BS		DRAWN BY: VGD	CHECKED BY: TD	APPROVED BY: TD	DATE: 1-23-85	SCALE: NONE	SIZE A	DRAWING NUMBER S5812BS	B	SMITH® JAY R. SMITH MFG. CO.® MEMBER OF MORRIS GROUP INTERNATIONAL POST OFFICE BOX 3237 MONTGOMERY, ALABAMA 36109-0237 (USA) TEL: 334-277-8520 FAX: 334-272-7396 www.jrsmith.com MEMBER OF: LOCATION																																																			
	PARTS LIST WITH MAINTENANCE INSTRUCTIONS																																																													
*These parts are accessible from face of hydrant by removing facenut.																																																														
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="4" style="text-align: left; padding: 5px;">REPLACEMENT PARTS LIST - SPECIFY FIGURE NO. WHEN ORDERING</th> </tr> <tr> <th style="width: 5%;">No.</th> <th style="width: 40%;">DESCRIPTION</th> <th style="width: 5%;">No.</th> <th style="width: 50%;">DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Head/Casing Assembly</td> <td>9</td> <td>Operating Screw "O" Ring</td> </tr> <tr> <td>1a</td> <td>Head</td> <td>10</td> <td>Operating Rod Assembly</td> </tr> <tr> <td>1b</td> <td>Casing</td> <td>10a</td> <td>Coupling</td> </tr> <tr> <td>1c</td> <td>Valve Housing</td> <td>10b</td> <td>Rod</td> </tr> <tr> <td>2</td> <td>Locking Device</td> <td>10c</td> <td>Plunger</td> </tr> <tr> <td>3</td> <td>Key</td> <td>11</td> <td>Washer Screw (No. 10-24)</td> </tr> <tr> <td>4</td> <td>Cover</td> <td>12</td> <td>Washer (Neoprene)</td> </tr> <tr> <td>5</td> <td>Hydrant Cover Hinge Pins (2)</td> <td>13</td> <td>Removable Seat</td> </tr> <tr> <td>6</td> <td>Box</td> <td>17</td> <td>Plunger "O" Ring</td> </tr> <tr> <td>7</td> <td>Face Nut</td> <td>19</td> <td>Face Nut Seat</td> </tr> <tr> <td>8</td> <td>Operating Screw</td> <td>20</td> <td>Face Nut Seat Gasket</td> </tr> </tbody> </table> ▲THESE REPLACEMENT PARTS AVAILABLE IN HPRK - 5 MAINTENANCE INSTRUCTIONS 1. Shut off water supply. 2. Remove face nut. 3. Pull stem out for complete access to all working parts. 4. Check all working parts for replacement. 5. Replace complete stem assembly and face nut.											REPLACEMENT PARTS LIST - SPECIFY FIGURE NO. WHEN ORDERING				No.	DESCRIPTION	No.	DESCRIPTION	1	Head/Casing Assembly	9	Operating Screw "O" Ring	1a	Head	10	Operating Rod Assembly	1b	Casing	10a	Coupling	1c	Valve Housing	10b	Rod	2	Locking Device	10c	Plunger	3	Key	11	Washer Screw (No. 10-24)	4	Cover	12	Washer (Neoprene)	5	Hydrant Cover Hinge Pins (2)	13	Removable Seat	6	Box	17	Plunger "O" Ring	7	Face Nut	19	Face Nut Seat	8	Operating Screw	20	Face Nut Seat Gasket
REPLACEMENT PARTS LIST - SPECIFY FIGURE NO. WHEN ORDERING																																																														
No.	DESCRIPTION	No.	DESCRIPTION																																																											
1	Head/Casing Assembly	9	Operating Screw "O" Ring																																																											
1a	Head	10	Operating Rod Assembly																																																											
1b	Casing	10a	Coupling																																																											
1c	Valve Housing	10b	Rod																																																											
2	Locking Device	10c	Plunger																																																											
3	Key	11	Washer Screw (No. 10-24)																																																											
4	Cover	12	Washer (Neoprene)																																																											
5	Hydrant Cover Hinge Pins (2)	13	Removable Seat																																																											
6	Box	17	Plunger "O" Ring																																																											
7	Face Nut	19	Face Nut Seat																																																											
8	Operating Screw	20	Face Nut Seat Gasket																																																											
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">REV.</td> <td style="width: 10%; text-align: center;">DATE</td> <td style="width: 30%; text-align: center;">DESCRIPTION</td> <td style="width: 10%; text-align: center;">BY</td> <td style="width: 10%; text-align: center;">CKD. BY</td> <td style="width: 10%; text-align: center;">WEIGHT POUNDS</td> <td style="width: 10%; text-align: center;">VOLUME CUBIC FEET</td> <td style="width: 20%; text-align: center;"> FIGURE NUMBER 5812,5813,5814 </td> </tr> <tr> <td style="text-align: center;">B A</td> <td style="text-align: center;">9-22-93 6-30-93</td> <td style="text-align: center;">Added Note Submittal Update</td> <td style="text-align: center;">EMB EMB</td> <td style="text-align: center;">BS BS</td> <td></td> <td></td> <td></td> </tr> </table>											REV.	DATE	DESCRIPTION	BY	CKD. BY	WEIGHT POUNDS	VOLUME CUBIC FEET	FIGURE NUMBER 5812,5813,5814	B A	9-22-93 6-30-93	Added Note Submittal Update	EMB EMB	BS BS																																							
REV.	DATE	DESCRIPTION	BY	CKD. BY	WEIGHT POUNDS	VOLUME CUBIC FEET	FIGURE NUMBER 5812,5813,5814																																																							
B A	9-22-93 6-30-93	Added Note Submittal Update	EMB EMB	BS BS																																																										